


### KULLANIM KILAVUZU

Değerli Müşterimiz,  
Bu kullanım kılavuzu satın almış olduğunuz ürünün gerekli montaj bilgilerini içermektedir. Güvenliğiniz ve ürün ömrü için kullanım kılavuzunda yer alan güvenlik uyarıları ve garanti şartları talimatlarına uyunuz. Ürünle alakalı problem yaşamazınız durumunda kılavuzda mevcut olan iletişim bilgileri üzerinden bizlere ulaşabilirsiniz.

### MONTAJ ŞEMASI



### MONTAJ TALİMATLARI

- 1- Armatür direğini kurunuz ve kurulum yüksekliğine karar veriniz. Sensör algılama mesafesi 6-8 metredir.
- 2- 5 saat şarj süresinden sonra sensör paneli üzerinde bulunan açma-kapama butonu ile ürünü çalışır hale getirebilirsiniz.
- 3- Yeterli süre şarj edilen solar armatür 6-8 saat boyunca çalışır.
- 4- Hareketsiz ortamlarda Stand-by modu ile %50'lik bir aydınlatma sağlanabilir.
- 5-Ürünün kutusunda koruma sınıfı (IP) belirtilmiştir. Ürün koruma sınıfının belirttiği ortam ve iklim koşulları haricinde kullanılmamalıdır.
- 6- Kullanmadan önce ürünü tam şarj olduğundan emin olunuz. Armatür kullanıma hazırdır.

### GÜVENLİK VE UYARILAR

- Kullanma kılavuzunu okumadan armatürü bağlamayınız.
- Kullanmadan önce armatürün tam şarj olduğundan emin olunuz.
- Ürün koruma sınıfının belirttiği şartlar dışında ürünü kullanmayınız.
- Armatürün montajı mutlaka uzman kişiler tarafından gerçekleştirilmelidir.
- Güneşe maruz kalma süresi ürünün şarj etkisini doğrudan etkilediği için kullanım alanına dikkat etmek gereklidir.
- Ürün dahili pil nedeniyle uygun şekilde atılmalıdır. Patlama tehlikesinden dolayı asla ateşe atmayınız.

### GARANTİ ŞARTLARI

- Ürünlerimiz 2 yıl birebir değişim garantilidir.
- Garantinin geçerli olabilmesi için parçaların eksiksiz olarak teknik servis ekibine teslim edilmesi gerekmektedir.
- Ürünün ayıplı olması durumunda; 6502 sayılı Tüketicinin Korunması Hakkında Kanun'un 11. maddesi gereği; ücretsiz tamirin yapılması, tamiri yapılamayan ürünün yeni ürüne değiştirilmesi yaptırımları uygulanır.
- Kullanım talimatları dışında kullanılan ve kullanıcı hatasına maruz kalan ürünler garanti kapsamı dışındadır.

### Showroom:

Bereketzade Mah. Sair Ziya Paşa Cad. No:31/A/PK. 34421 Karaköy, Beyoğlu / İstanbul  
Tel: 0212 244 84 22-23 Pbx  
Mail: info@noas.com.tr

### Fabrika:


Beylikdüzü OSB Mh. Mustafa Kurtoglu Cd. No.23 (Bakırçılar Demirciler Sanayi Sitesi)  
Beylikdüzü / İstanbul  
Tel: 0212 879 03 53  
Web: www.noas.com.tr



## USER MANUAL

Dear Customer,  
This user manual contains the necessary installation information of the product you have purchased. For your safety and product life, follow the safety warnings and warranty conditions instructions in the user manual. If you have a problem with the product, you can contact us via the contact information available in the user manual.

## ASSEMBLY DIAGRAM



## ASSEMBLY INSTRUCTIONS

- 1- Install the luminaire post and decide on the installation height. The sensor detection distance is 6 to 8 meters.
- 2- After 5 hours charging, you can activate the product with the on-off button on the sensor panel.
- 3- The solar luminaire that is charged enough time will work for 6 to 8 hours.
- 4- In stationary environments, %50 illumination can be provided with the Stand-by mode.
- 5- The protection class(IP), is indicated the box of the product. It should be not be used out of the ambient and climatic conditions specified by the protection class.
- 6- Make sure the luminaire is fully charged before use. Luminaire is ready to use.

## SAFETY & WARNINGS

- Do not connect the panel without reading the user manual.
- Make sure the luminaire is fully charged before use.
- Do not use the product other than the conditions specified by product protection class..
- Installations of the luminaire must be carried out by specialists.
- Since the time of exposure to the sun directly affects the charging effect of the product, it is necessary to pay attention to the usage area.
- The product must be disposed properly due to build-in battery. Never throw it into the fire due to risk of explosion.

## WARRANTY CONDITIONS

- Our products are guaranteed for one-to-one replacement for 2 years.
- In order for the warranty to be valid, the parts must be delivered to the technical services completely.
- In case the product is defective; Pursuant to Article 11 of the Consumer Protection Law No:6502; Sanctions are applied to make free repair, to replace the product that cannot be repaired with a new product.
- Product that are used outside the instructions for use and exposed to user error are not covered by warranty.

### Showroom:

Bereketzade Mah. Sair Ziya Paşa Cad. No:31/A PK. 34421 Karaköy, Beyoğlu / İstanbul  
Tel: 0212 244 84 22-23 Pbx  
Mail: info@noas.com.tr

### Factory:

Beylikdüzü OSB Mh. Mustafa Kurtoglu Cd. No.23 (Bakırcılar Demirciler Sanayi Sitesi)  
Beylikdüzü / İstanbul  
Tel: 0212 879 03 53  
Web: www.noas.com.tr

